

MPPT-10 MPPT-20
Solar Charge Controller

10A/20A 12V/24V/48V auto switch
INTELLIGENT SOLAR CHARGE CONTROLLER

INSTALLATION AND OPERATION

MANUAL



TABLE OF CONTENT

1. Introduction.....	1
2. Function.....	1
3. Comparison.....	5
4. Data Sheet.....	6

I.Introduction

The most outstanding feature of Maximum Power Point Tracking controller is intelligent tracking input voltage from solar panel, which could let solar panel always working at Maximum Power Point of V-A curve. Compared with normal solar charge controller, this MPPT controller could increase 10%-30% electrical power using efficiency from solar panel.

II.Function:

This MPPT controller is not only have above mentioned special function, at the same time including completely Protecting and Controlling functions:

Overcharge protection


Over-discharge protection

Battery Reverse Current Protection

Overloading Protection

Short Circuit Protection

Reverse Polarity Connection Protection



Schematic Diagram: Picture 2 shows typical 12V battery solar charge system V-A curve.

Normal Solar Charge Controller: Solar Panel works at point A state, the solar panel working voltage is a little higher than battery voltage.

Charge Voltage: $U_A=13.2V$

Charge Current: $I_A=9.8A$

Charge Power: $P_A=13.2*9.8=129.36w$

Area in drawing: ①+③

MPPT Solar Charge Controller: Solar Panel works at point B state, the solar panel working voltage much higher than battery voltage.

Charge Voltage: $U_B=18.4V$,

Charge Current: $I_B=9.3A$

Charge Power: $P_B=18.4*9.3=171.12w$

Area in drawing: ①+②

III.Comparison:

The power B is more than power A..

$$\Delta P / PA = (PB - PA) / PA = 32.3\%$$

As a result of different manufacture of solar panels, different solar illumination intensity, different temperature, different efficiency of solar charge controller and so on. The effective power increase rate is 10-30%.


Form a complete set:

Solar Panel: 12V solar system should use 40pcs cells laminated solar panel. The maximum power point voltage is 18V above. 24V solar system should use 2pcs above mentioned solar panels. 48V solar system should use 4pcs above mentioned solar panels.

Conductor: The cable between solar panel with MPPT solar charge controller should be better calculated by 1Ampere per 1mm².

Solar Charge Controller: MPPT-10 Model solar charge controller Rated input Ampere is 10A. We have 12V, 24V and 48V three kinds of MPPT solar charge controllers (other specifications could be designed as customer special request). Fit for power of solar panels: 20—200Wp (12V) , 40—400Wp (24V) , 80-800Wp (48V).

IV.Connection: (As Picture 3 according to below process)



1. Connected the “+”, “-” poles of the battery to the controller (3, 4 from left) firmly and correctly. At this time the LOAD green LED is bright. If the LOAD green LED is not bright, it is indicate there is battery reverse polarity connection. **Only LOAD green LED is bright, we could continue next step operation.**
2. Connected the “+”, “-” poles of the solar panel to the controller (1,2 from the left) firmly and correctly.

3. Connected the “+”, “-” poles of the LOAD to the controller (5,6 from the left) firmly and correctly.

Simply Measure Method: For 12V system, measure the input voltage from solar panel with multimeter (terminal 1, 2 of controller), it is normal if the voltage of solar panel more than battery voltage 0.5-6V. Generally, the higher input voltage, the better charge efficiency.

For 24v and 48V system, the input

voltage will be much more higher than battery voltage

(Note: It is normal the controller can not find Maximum Power Point within 10 minutes from system start.)

Indicator: (Picture 1)

1. Load indicator, green, bright indicate there is output, Load could work, “off” indicate there is not output, Load can not work.
2. Low Voltage Indicator, red, bright indicate the voltage of the battery is low. Load could not normal working. This is normal phenomenon. When the battery voltage recovers to 12.6V or (25.2v), the Load will be automatically working, at this time the indicator is off.
3. Charge Indicator, red, bright indicate the battery need to charge, flickering means float charging, off means charge has stop.

RESET Button: The rated output current of this MPPT solar charge controller is 10A, if there is short circuit or overload happened, the MPPT controller will close output. (Load indicator off, Low voltage indicator off.)

If you need the MPPT controller recover work, please check the reasons and clear out the fault firstly. Then put a small stick such as toothpick, ball-pen tip inside the RESET hole, and press RESET button will be OK.

Attention:

1. **Please check the rated voltage of the solar panel, battery, load are all the same with 12V or 24V or 48V.**
2. **Please pay attention to connection, do not connect the “+” “-” poles of battery and solar panels wrong.(Wrong connection will be burn your MPPT controller)**

3. Battery must be connected earlier than solar panels and load. When take off the system, Solar Panels must be take down first, then cut off battery.
4. The rated current of solar panel and load must be less than MPPT controller's rated current.

V.Data Sheet

Model	MPPT-10	MPPT-20
Rated Voltage	DC: 12V / 24V / 48V	
Max Current	10A	20A
Zero Loaded Losses	≤45mA/12V / 24V	≤25mA/48V
Full Charge Cut	14V/12V,×2/24V,×4/48V	
Low Voltage Cut	10.5V/12V,×2/24V,×4/48V	
Supply Resume Voltage	12.6V/12V,×2/24V,×4/48V	
Temp Compensation	-3mV/cell	
Efficiency	95%~97%	
Min. Wire Size	1~2A/ mm ²	
MPPT Efficiency	Increase 10~30%	
Net Weight	0.55Kg	0.65Kg
Dimension	188×93×55mm	188×118×55mm